



Instruction Manual


Pop-Up Wall Magnetic




1. Open the case and take out the Pop-Up Frame.




2. Place the frame in front of you with the label 'Frontside Top' facing away from you.



3. Open the frame slightly by pulling the hinges outwards.




4. Gently lift up the frame, while flipping it over.



5. Place your hands on the bars as shown in the picture.




6. The Pop-Up Frame unfolds as you lift it up further.



7. Push the red marks towards each other, until all magnetic clips are connected.




8. Open the bag and take out the magnetic bars.



9. Attach the bars to the frame in vertical rows
Note: keep the two upper magnets free.



10. Place the bars with the label 'Bottom Bar' on the bottom of the frame.



11. Place the bars on the frontside, and on the left- and right side of the backside.



12. Attach the print to the frame, by 'hanging' them on top of the magnetic bars



13. Gently 'kick' the bottom to connect it to the frame, the magnetic strips should cover the bars halfway



14. Use the bars on both the front- and backside of the frame for the panels that go around the sides.



15. Attach all panels to the frame, the Pop-Up Magnetic is now ready for use.

Instruction Manual

Disassemble



1. Take one edge of the printed panel and carefully disconnect it from the frame.



2. Gently place the prints on top of each other. All magnetic strips should be in the same position.




3. Roll-up the print panels as one, and place them in the right section of the case for storage.




4. Disconnect all magnetic bars from the frame.



5. Stack the bars on top of each other. All magnets should be in the same position to prevent loss of power.



6. Place your hands on the flat side of the hinges to prevent your fingers from getting stuck.



7. Open the magnetic clips with a firm pull downwards, and fold in the frame.



8. Place the frame in the left (padded) section of the case. Lock for safe and durable storage.



Scan for instructional video



**DIE WERBE
ARCHITEKTEN**
dieWerbearchitekten.com

Optional:
Convert Case
to Counter



1. Wrap the print around the Hard Case, and connect the Velcro on the backside.

2. Fold open the table top and put it in place.



3. The Counter is now ready to use.

